

Manufacture	System	Part No.	Description
Epson	RC180	R12NZ9003X	CC-Link Board
Epson	RC180	2115548	Switching Power Supply (15V)
Epson	RC180	1453090	Fan Filter For Option Unit
Epson	RC180	2150335	Motor driver (MDB)- 50W
Epson	RC180	2150337	Motor driver (MDB)- 150W & 200W
Epson	RC180	2150338	Motor driver (MDB)- 400W
Epson	RC180	2158127	DPB(G10/G20/C3/S5)
Epson	RC180	2120271	DMB
Epson	RC180	2150336	Motor driver (MDB)- 100W
Epson	RC180	2147295	CF (Compact Flash)
Epson	RC700	2171247	Motor driver (MDB) 15A/15A
Epson	RC700	2176557	Motor Driver (5A/5A)
Epson	RC700	1605921	Switching Power Supply (15V)
Epson	RC700	2150251	Circuit protector
Epson	RC700	2151349	DMB-SUB for RC700
Epson	RC700	2150249	Switching Power Supply (24V)
Epson	RC700	2171246	DPB
Epson	RC700	2111451	TP/OP Bypass Plug
Epson	RC700-A	2171253	DPB For RC700A
Epson	RC700-A	2168582	Motor Driver 15A/15A Ver.2
Epson	RC700-A	2171259	Motor Driver (50A/30A)
Epson	RC700-A	2171456	Motor Driver (30A/30A)
Epson	RC90-B	2197078	CF Card, COMPACT FLASH FOR RC90B_BT_ASP
Epson	RC90	R12NZ90001	CF card, MT681 Upgrade Kit for RC90
Epson	RC90	2166272	CF card
Epson	RC90	1520975	Fan Filter(RC620)
Epson	RC620	2128931	DPB
Epson	RC620	2130994	DMB for RC620DU
Epson	RC620	1593217	CF (Compact Flash)
Epson	RC620	2182313	DMB(ETX-AT(SK3) & CF)
Epson	RC620	1520975	Fan Filter(RC90)
Epson	RC620	1520974	Fan Filter A

Epson	G10	2158127	驅動電源板DPB(G10/G20/C3/S5)
Epson	G10	1489329	Timing Belt
Epson	G10	1499575	Ball Screw Spline
Epson	G10	1499576	Ball Screw Spline
Epson	G10	1620040	J2 Shaft Unit G10/G20 set
Epson	G10	1497639	Solenoid Brake(C3,G10,G6,RS3)
Epson	G10	1499535	Reduction Gear Unit,1499535/ R13B031601(G10,G20)
Epson	G10	1620039	J1 Shaft Unit for G10/G20
Epson	G10	1489327	Reduction Gear Unit(G10:J1)
Epson	G10	1525071	Reduction Gear Unit
Epson	G10	1489326	Reduction Gear Unit(G10,G20)
Epson	G10	1497624	AC Servo Motor 400W(G6 J1/J2,G10)
Epson	G10	1499527	AC Servo Motor
Epson	G10	1499528	AC Servo Motor
Epson	G10	1499529	AC Servo Motor SGMAS-C2A2AA1-E
Epson	G10	2158127	DPB (G10/G20/C3/S5), (RC180)
Epson	C3	1538315	關節2煞車 For C3
Epson	C3	1538316	關節3煞車 For C3
Epson	C3	1595246	關節5煞車 For C3
Epson	C3	2158127	驅動電源板DPB(G10/G20/C3/S5)
Epson	C3	1497639	Solenoid Brake (C3,G10,G6,RS3)
Epson	C3	1480756	Harmonic Reduction Gear Unit/HD25-50 (G6/C3:J2)
Epson	C3	1480755	Harmonic Reduction Gear Unit/HD25-80 (G6/C3:J1)
Epson	C3	1514468	Motor For J1,J2 (C3/G6 J1/J2)
Epson	C3	1533638	Motor For J3
Epson	C3	R12NZ9202H	M/C Cable 3m (180/620)
Epson	C3	2120180	Battery Board
Epson	C3	1520354	Timing belt for J2
Epson	C3	1520355	Timing belt for J3
Epson	C3	1520406	Timing belt for J5
Epson	C3	1520357	Timing belt for J6
Epson	C3	1668266	J5_motor_plate_C3_ASP
Epson	C3	1533644	Motor For J5,J6

Epson	C3	2158127	DPB(G10/G20/C3/S5), (RC180)
Epson	C3	1520394	Timing belt for J1, (C3/C4)
Epson	C3	1520356	Timing belt for J4
Epson	C3	1539261	Harmonic Reduction Gear Unit CSD-14-50, (C3/C4 J6)
Epson	C3	1520374	O-Ring, CO0511A, (C3:ARM5)
Epson	C3	1510528	O-Ring, CO0551A, (C3:J2)
Epson	C3	1625505	BEARING
Epson	C3	1520371	O-Ring, CO0538A, (C3:ARM3-4)
Epson	C4	1605913	Brake (C4/J4/J5/J6)
Epson	C4	1667824	Pinion Gear
Epson	C4	2155583	Cable unit (C4-A901C)
Epson	C4	2165179	ARM 1_SIDE_COVER_C_C4
Epson	C4	2165176	ARM 3_HEAD_COVER_C4
Epson	C4	2165177	ARM 4_SIDE_COVER_R_C4
Epson	C4	2165178	ARM 4_SIDE_COVER_L_C4
Epson	C4	2177458	Battery Board without Battery
Epson	C4	2176222	HARNESS CABLE /HP_Harness_A_SW1 (C4/C8)
Epson	C4	1520394	Timing belt for J1 (C3/C4)
Epson	C4	1539261	Harmonic Reduction Gear Unit CSD-14-50 (C3/C4 J6)
Epson	C4	2149411	Cable unit (C4-A601)
Epson	C8	1655919	Timing belt
Epson	C8	1655927	Timing belt
Epson	C8	1655930	Timing belt
Epson	C8	1655931	Timing belt
Epson	C8	1655932	Timing belt
Epson	C8	1655933	Timing belt
Epson	C8	2172926	ASP/Brake + Power RNB 0.2G-45
Epson	C8	2172922	ASP/Motor Unit (C8L/C8XL,J1:1000W)
Epson	C8	2168683	AC Servo Motor
Epson	C8	2168684	AC Servo Motor
Epson	C8	1674604	ASP/Reduction Gear Unit (C8:J1)
Epson	C8	1674608	ASP/Reduction Gear Unit
Epson	C8	1674609	ASP/Reduction Gear Unit

Epson	C8	1674610	ASP/Reduction Gear Unit (C8:J5/J6)
Epson	C8	2172931	Cable unit for C8XL (Standard/Clean Model)
Epson	C8	1678606	ASP/Reduction Gear Unit
Epson	C8	2173216	Battery Board-B
Epson	C8	2172927	ASP/Brake + Power MCNB 10-59 (C8/J3)
Epson	C8	2172051	ASP/AC Servo Motor
Epson	C8	2176222	HARNESS CABLE /HP_Harness_A_SW1 (C4/C8)
Epson	C8	2172925	Battery Set (N2/C8)
Epson	C8	2172928	ASP/Brake + Power MCNB 3-45 (C8:J4/J5/J6)
Epson	G6	2123758	驅動電源板DPB(G1/G3/G6/PS/RS)
Epson	G6	1497628	Ball Screw Spline
Epson	G6	1497639	Solenoid Brake, (C3,G10,G6,RS3)
Epson	G6	1480756	Harmonic Reduction Gear Unit/HD25-50 (G6/C3:J2)
Epson	G6	1480755	Harmonic Reduction Gear Unit/HD25-80 (G6/C3:J1)
Epson	G6	1514468	Motor For J1,J2, (C3/G6 J1/J2)
Epson	G6	1497625	AC Servo Motor
Epson	G6	1497626	AC Servo Motor 100W, (G6:J4)
Epson	G6	1514469	AC Servo Motor 100W, (G6/RS3_RS4:J4)
Epson	G6	1620037	J1 Shaft Unit
Epson	G6	1497640	Solenoid Brake
Epson	G6	1497624	AC Servo Motor 400W, (G6 J1/J2,G10)
Epson	G6	1514451	AC Servo Motor 200W, (G6:J2:J3)
Epson	G6	1620038	J2 Shaft Unit
Epson	S5	2158127	驅動電源板DPB(G10/G20/C3/S5)
Epson	S5	1551089	J5減速機 for S5
Epson	S5	1551113	Timing Belt, (S5:J2)
Epson	S5	1551115	Timing Belt, S5-A901S, (S5:J3)
Epson	S5	1551116	Timing Belt, (S5:J4)
Epson	S5	1551117	Timing Belt, (S5,J5,J6)
Epson	S5	1551282	Electromagnetic Brake
Epson	S5	1551084	Reduction Gear Unit
Epson	S5	1551086	Reduction Gear Unit
Epson	S5	1551088	Reduction Gear Unit

Epson	S5	1551089	Reduction Gear Unit
Epson	S5	1601749	Solenoid Brake
Epson	S5	2136798	AC Servo Motor, (S5/J1&J2)
Epson	S5	2136799	AC Servo Motor, (S5/J3)
Epson	S5	2158127	DPB(G10/G20/C3/S5), (RC180)
Epson	LS3	1661087	Reduction Gear Unit
Epson	LS3	1554773	Timing belt for J3
Epson	LS3	1554775	Timing belt for J4
Epson	LS3	1554777	Timing belt for J4
Epson	LS3	1593211	LS3 Ball Screw Spline, (LS3,LS6)
Epson	LS3	1593406	LS6 Ball Screw Spline, (LS3,LS6)
Epson	LS3	1593212	Ball Screw Spline
Epson	LS3	1653819	O-Ring, J2
Epson	LS3	1650901	O-Ring
Epson	LS3	1653181	O-Ring, J1
Epson	LS3	1213267	O-Ring, J1
Epson	LS3	1213266	O-Ring, J2
Epson	LS6	1497640	煞車-U軸 For LS6
Epson	LS6	1593407	Ball Screw Spline
Epson	LS6	1750573	Electromagnetic Brake Unit, (LS6-B)
Epson	LS6	1593211	LS3 Ball Screw Spline, (LS3,LS6)
Epson	LS6	1593406	LS6 Ball Screw Spline, (LS3,LS6)
Epson	LS6	1649162	Harmonic Reduction Gear Unit, (LS6/J2)
Epson	RS	2123758	驅動電源板DPB(G1/G3/G6/PS/RS)
Epson	RS	1497639	Solenoid Brake, (C3,G10,G6,RS3)
Epson	RS	1514453	AC Servo Motor, (RS3/RS4:J3)
Epson	RS	1514469	AC Servo Motor 100W, (G6/RS3_RS4:J4)
Epson	RS	1547166	Cable unit, (RS4)
Epson	PS3	2123758	驅動電源板DPB(G1/G3/G6/PS/RS)
Epson	PS3	1419409	Harmonic Reduction Gear for J1, (PS5/3L/3LP:J1)
Epson	PS3	1290307	Harmonic Drive Reduction Gear Unit, (PS3:J4)
Epson	PS3	1290306	Harmonic Drive Reduction Gear Unit, (PS3:J3)
Epson	PS3	1290304	Harmonic Drive Reduction Gear Unit, HW0383248-A, (PS3:J5)

Epson	PS3	1421615	Harmonic Drive Reduction Gear Unit, (PS5/3L/3LP/PS3:J2)
Epson	PS3	1290308	Reduction Gear Unit, HW0382065, (PS3/J6)
Epson	PS3	2106017	Motor J3(200W), SGMPH-02A2A-YR21, HW0383252-A, (PS3L)
Epson	PS3	R12B020401	M/C Power Cable 3M, (PS3L)
Epson	PS3	R12B020701	M/C Signer Cable 3M, (PS3L)
Epson	PS3	6022397	Grease For Reduction Gear 500g, 4BNo2, (PS3L)
Epson	PS3	2106016	Motor for J1,J2 (400W), SGMPH-04A2A-YR22 (PS3L)
Epson	PS3	1290309	Timng belt For J5, (PS3L)
Epson	PS3	1290310	Timng belt For J6, (PS3L)
Epson	PS3	2090017	Motor for J4,J5&J6(50W), SGMAH-A5A2A-YR11, HW0382149-A, (PS3L)
Epson	PS3	2090012	Battery, (PS3L)